



Nintendo Switch™ Joy-Con™

Health and Safety Information

Please read and observe the health and safety information. Failure to do so could result in injury or damage. Adults should supervise the use of this product by children.

⚠ WARNING – Batteries

- Stop using this product if batteries are leaking. If battery fluid comes into contact with your eyes, immediately rinse your eyes with plenty of water and consult a doctor. If any fluid leaks on your hands, wash them thoroughly with water. Carefully wipe the fluid from the exterior of this product with a cloth.
- The product contains a rechargeable lithium-ion battery. Do not replace the batteries yourself. The batteries must be removed and replaced by a qualified professional. Please contact Nintendo Customer Support for more information.

⚠ WARNING – Electrical Safety

- Use only the Nintendo Switch console (HAC-001/HEG-001) or the Joy-Con charging grip (HAC-012) (sold separately) to charge this product.
- If you hear a strange noise, see smoke or smell something strange, stop using this product and contact Nintendo Customer Support.
- Do not expose device to fire, microwaves, direct sunlight, high or extremely low temperatures.
- Do not let this product or built-in batteries come into contact with liquid and do not use this product with wet or oily hands. If liquid gets inside, stop using this product and contact Nintendo Customer Support.
- Do not expose this product or built-in batteries to excessive force.
- Do not touch this product or connected devices while charging during a thunderstorm.

⚠ WARNING – General

- Keep this product and packaging materials away from young children. Packaging items may be swallowed.
- Do not use this product within 15 centimetres of a cardiac pacemaker while using wireless communication. If you have a pacemaker or other implanted medical device, first consult a doctor.
- Wireless communication may not be allowed in certain places such as aeroplanes or hospitals. Please follow respective regulations.
- Persons who have an injury or disorder involving their fingers, hands or arms should not use the vibration feature.
- Do not disassemble or try to repair this product or built-in batteries. If there is any damage, stop using the product and contact Nintendo Customer Support. Do not touch damaged areas. Avoid contact with any leaking fluid.

CAREFUL USAGE

- If this product becomes dirty, wipe it with a soft, dry cloth. Avoid using thinner or other solvents.
- Make sure to charge built-in batteries at least once every six months. If batteries are not used for an extended period of time, they may become impossible to charge.

How to Use

Charge and pair controllers before using them for the first time. You can charge and pair controllers by attaching them directly to the Nintendo Switch console (HAC-001/HEG-001) or using the Joy-Con charging grip (HAC-012) (sold separately).

Nintendo Customer Support

<https://nintendo.sa>

Disposal of this Product

Do not dispose of this product or built-in batteries in household waste. For details see <https://nintendo.sa/support> or <https://docs.nintendo-europe.com>

The battery should be removed by a qualified professional. Visit <https://battery.nintendo-europe.com> for more information.

Technical Specifications

Joy-Con (L)	Operating frequency band(s)	Maximum radio-frequency power
Bluetooth®	2402-2480MHz	4dBm

Joy-Con (R)	Operating frequency band(s)	Maximum radio-frequency power	Maximum field strength
Bluetooth	2402-2480MHz	4dBm	-
NFC	13.56MHz	-	-6dBµA/m

For explanation of the symbols and markings used on this product, see <https://docs.nintendo-europe.com>

DECLARATION OF CONFORMITY

Hereby, Nintendo declares that the radio equipment type (Nintendo Switch Joy-Con) is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://docs.nintendo-europe.com>



Manufacturer: Nintendo Co., Ltd., Kyoto 601-8501, Japan

Importer in KSA: AIC Trading Ltd 8113 Al Thoumamah Rd, Ar Rabi, Riyadh 13315

MODEL NO. : Joy-Con (L): HAC-015 / Joy-Con (R): HAC-016 / Joy-Con Strap: HAC-014

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Nintendo is under license. Other trademarks and trade names are those of their respective owners.

© Nintendo

Trademarks are property of their respective owners. Nintendo Switch and Joy-Con are trademarks of Nintendo.